

Quick Start Guide
TCP/IP TO RS-232/422/485 Device Server
MODEL XS1000



1. Package Content

- XS1000 serial to Ethernet server
- XS1000 Documentation (downloadable)
- 9VDC power adapter

2. Hardware Installation

- Use a standard Ethernet cable to connect the XS1000 to an Ethernet switch (Fig. 1), or use a cross-over cable if you connect it directly to a PC (Fig. 2).




Fig. 1




Fig. 2

RS-232 Pin configuration: (DB9 Male)

(DB9Male)	Signal	I/O
PIN2	RXD	IN
PIN3	TXD	OUT
PIN5	GND	-

RS-422/485 Pin configuration: (Terminal header)

Terminal No	1	2	3	4	5	6
RS-422	T+	T-	R+	R-	VIN	GND
RS-485	485+	485-	-	-	VIN	GND

- Connect the power adapter to the XS1000 (+9 to 24VDC, 1000mA).

3. LED indication


- LINK: Ethernet Link established.
- ACT: Data flow TX/RX.
- PWR: Power ON.

4. Software Installation

- Install VCOMSETUP.exe from the included CD-ROM or download the latest version from www.USconverters.com.
Note: Be sure you have administrative rights and disable any firewalls.

5. Configuring the XS1000

- Assign a static IP address to your computer in the **192.168.2.2 to 192.168.2.254** range. Subnet mask 255.255.255.0. This is necessary to ensure that your computer can communicate with your XS1000. Your computer must have an Ethernet card and TCP/IP installed. TCP/IP should already be installed on computer using Windows 98/2000/XP and later operating systems.
- The **default IP address of the XS1000 is 192.168.2.1**. Open your web browser and enter this IP address to connect to the XS1000.
- Default user name is **'admin'** and the password is **'system'**. Click "OK". The setup screen will then appear, and you can now configure the settings.
- Create a new COM port using VCOM.exe.



Please download drivers and manuals from
WWW.USCONVERTERS.COM